

# **SDS Data Logger**

Application Notes Rev. 01A Aug. 2021

SIGLENT TECHNOLOGIES CO.,LTD

# Catalogue

The SDS1000X-E Data Logger	.2
Setting the System Time	.2
Data Logger: Sample Logging	.3
Sample Logger Pre-test considerations	.3
Logging with the Sample Logger	.4
Recall a logged file in the Sample Logger	.4
Analyzing a Sample Logger file on a PC	.5
Data Logger: Measure Logger	.6
Measure Logger Pre-test considerations	.7
Logging with the Measure Logger	.7
Analyze, Save and Recall the Measure Logger data.	.7
Analysing a Measure Logger file on a PC	.8

# The SDS1000X-E Data Logger

Numerous test and measurement applications require data acquisition over a long time duration. Instead of milliseconds of measurement time, you may need tens of minutes or even hours of data. Normally, a data acquisition system is used for this type of application. But this may require developing software and troubleshooting code. SIGLENT has added a data logging mode to the SDS1000X-E oscilloscope series that makes it easier than ever to collect long time duration data. The SIGLENT Data Logger continuously records original sampling points and measurement values.

SIGLENT Aut	o M 1.00us/	Delay:0.00s		1992 I I I I I I I		1.1	f	< 10Hz
								0GSa/s
								4.0kpts
							Edge	CH1
a an							£	DC
1							L	0.0V
							1	DC1M
							1X	1.00√/ 2.08√
8							3	DC1M
							1X	1.00V/ 0.0V
UTILITY								
					[]	Next Page		
Pass/Fail 💊	٧O	C C	ounter 🛬	Bode Plot II🕹	Data Logger	Page 2/4	ᇾ	
-								
DATA LOGGER	and an exception of the	_						
Sample Logger 🕈	Measure Logger	*				Ţ	쁆	

# Setting the System Time

The SIGLENT SDS1000X-E oscilloscopes do not have a system clock. If you want the time of data logger to be the correct time, you need to set the system time after power on. You can set the system time manually or configure the network time server address to get the time from the network time server through NTP as shown below:

UTILITY						
Update 🔸	Do Self Test	Screen Saver Off	Options 🔸	Date/Time 🔸	Next Page Page 3/4	┺
DATE/TIME						
Date/Time 🔸		NTP 🔸	Display Off		ļ	₴₽

**The Sample Logger** 

The Sample Logger continuously samples and stores measurement points. It is ideal for the long-time observation of low-speed signals. Because the original points are recorded for a long time, the amount of data can be very large. Since the DDR memory of the oscilloscope is limited, the sampling points are saved to the internal flash of the machine or an external U disk (USB memory device) in real time. After stopping the acquisition, the user can not only look back at the sampling point on the oscilloscope, but also analyze the saved data on the computer.





#### Sample Logger Pre-test Considerations

The Sample Logger logs the enabled channels. Before beginning, you should:

- 1. Configure the scaling, type, and enable the required input channels so that each can collect the signals you wish to record.
- 2. What's the sample rate of Sample Logger based on your settings?
- 3. How long do you wish to log data?

#### WWW.SIGLENT.COM

- 4. Calculate the amount of the data required.
- 5. Decide to log to internal flash memory or an external U disk.

## Logging with the Sample Logger

The steps to log:

- Enable the channels and set the channel parameters.
- Enter the Sample Logger and config the parameters.
- 3. Start and stop logging

SAMPLE LOG Record 🔸	Recall 🔸	Manage 🔸	Exit 😴
RECORD Settings 🔸	Start	Recall 🔸	*
SETTINGS Rate 25.0kSa/s	Record to Internal		*
RECORD			splg_int.slg
Settings 🔸	Stop	Recall 🔸	<del>- 26</del>

In order to reduce the amount of data logged and speed up the logging, the log file is recorded as binary, and the file name is \*.slg. The file format is described in the "how to extract data from the binary file.docx" document. Please download this document from an official SIGLENT website.

#### Recall a logged file in the Sample Logger

The Sample Logger can recall samples from a U disk or flash memory to the scope where they can be viewed and analyzed. The DDR of the oscilloscope is limited. If the waveform data exceeds the DDR capacity, the U disk will be read during operation, so please do not pull out the U disk when analyzing the samples.

1. Recall samples.

SAMP	LE LOG										
Re	ecord 🖣	r	Reca	all 🔸	Manage 🔸			Ex	it	<mark>(</mark> 라	
SIGL	ENT	Roll	M 50.0r	ns/ Del	ay:0.00s						< 10Hz
											IOMSa/s
											40Mpts
			U-disk	o.						Edge	CH1
			0-disk	U/							
Þ											
				System	Volume Information					1	DC1M
				Splg01.	slg	16.47	MB				1.00V/
											2.02V
											DC1M
											1.00V/ -2.04V
											2.011
•											
RECAL	LL						_				
Re	name 🖣	×	Delet				Press Reca	↓		e 몽	

- 2. Use the time base and delay knob to adjust the waveform.
- 3. Use the cursors.



# Analyzing a Sample Logger file on a PC

In order to analyze on the PC, the logged file in the flash can be exported to U disk.



The oscilloscope provides a tool for converting logged files (.slg) to CSV: fileconverter. You can export this tool in the save/recall

menu of the oscilloscope or from the oscilloscopes web page (four-channel X-E models, only).



#### WWW.SIGLENT.COM



You can also parse the \*.slg file with your own program. The file format is described in the "how to extract data from the binary file.docx" document. Please download the document from an official SIGLENT website.

# Data Logger: Measure Logger

The measure logger collects measurement samples and shows the trending over time of low-speed signals. Because the amount of measurement data is relatively small, in order to process it quickly, the data is logged in the oscilloscope memory. After logging is complete, the data can be saved into the internal flash or external U disk, and imported to the PC.





# Measure Logger Pre-test Considerations

The measure logger logs the currently selected measured items. Before beginning, you should think of:

- 1. What are the measured items you want to log?
- 2. What is the sample interval and duration you require?

#### Logging with Measure Logger

1. Enable the measurement items you want to log.



2. Enter the Measure Logger and config the parameters.

UTILITY Pass/Fail 🔸	Max[1]=1.04V	Min[3]=1.40V Counter 🔸	Bode Plot II🔸	Data Logger	Next Page Page 2/4	品
DATA LOGGER Sample Logger +	<sup>Max[1]=1.28V</sup> Measure Logger ✦	Min[3]=1.64V			ţ	쁆
MEASURE LOG Settings 🔸	Start	Display 🔺 All	Horizontal Ref Right	Save/Recall₊	Exit	쁆
SETTINGS Log Interval 0.1s	Select 🔺 Trace 1	Measure Item Max[1]			IJ	쁆

3. Start and stop logging.

MEASURE LOG						
Settings 🔸	Start	Display 🛧 All	Horizontal Ref Right	Save/Recall₊	Exit	<del>- 12</del> -

### Analyze, Save and Recall the Measure Logger data.

- 1. Use the time base and delay knob to adjust the waveform.
- 2. Use the cursors.



3. Save and Recall the logged data.

MEASURE LOG	T1: 1970-01-01 06:	40:12.1 T2-T1:	0d00:00:25.5	T2: 1970-01-0 <sup>-</sup>	1 06:40:37.6		
Settings 🔸	Start	Display 🛧 All	Horizontal Ref. Center	Save/Recall <b>.</b>	Exit	융	
SAVE/RECALL T1: 1970-01-01 06:40:12.1 T2-T1: 0d00:00:25.5 T2: 1970-01-01 06:40:37.6							
Save 🔸	Recall 🔸	Export Internal Data	Delete Internal Data		ļ	<del>- 88</del>	

You can save the logged data into Flash or U disk. The logged file is saved as binary, and the file name is \*.mlg. The file format is described in the "how to extract data from the binary file.docx" document. Please download this document on the official website of Siglent.

# Analyzing a Measure Logger file on a PC

In order to analyze on the PC, the logged file in the flash can be exported to a U disk.

MEASURE LOG	T1: 1970-01-01 06:	40:12.1 T2-T1:	0d00:00:25.5	T2: 1970-01-0	1 06:40:37.6	
Settings 🔸	Start	Display 🛧 All	Horizontal Ref Center	Save/Recall₊	Exit	꿂
SAVE/RECALL	T1: 1970-01-01 06:	4 <u>0:12.1 T2-T1:</u>	0d00:00:25.5	T2: 1970-01-0	1 06:40:37.6	
Save 🔸	Recall 🔸	Export Internal Data	Delete Internal Data		ļ	<del>- 22</del>

The oscilloscope provides a tool for converting logged file (.mlg) to CSV: fileconverter. You can export this tool in the save/recall menu

of the oscilloscope or in the web page.

You can also parse the \*.mlg file with your own program. The file format is described in the "how to extract data from the binary

file.docx" document. Please download the document from an official SIGLENT website.

For more details about the specification or the operation, please refer to the product data sheet and the user manual.

# SIGLENT<sup>®</sup>

#### About SIGLENT

SIGLENT is an international high-tech company, concentrating on R&D, sales, production and services of electronic test & measurement instruments.

SIGLENT first began developing digital oscilloscopes independently in 2002. After more than a decade of continuous development, SIGLENT has extended its product line to include digital oscilloscopes, isolated handheld oscilloscopes, function/arbitrary waveform generators, RF/MW signal generators, spectrum analyzers, vector network analyzers, digital multimeters, DC power supplies, electronic loads and other general purpose test instrumentation. Since its first oscilloscope was launched in 2005, SIGLENT has become the fastest growing manufacturer of digital oscilloscopes. We firmly believe that today SIGLENT is the best value in electronic test & measurement.

#### Headquarters:

SIGLENT Technologies Co., Ltd Add: Bldg No.4 & No.5, Antongda Industrial Zone, 3rd Liuxian Road, Bao'an District, Shenzhen, 518101, China Tel: + 86 755 3688 7876 Fax: + 86 755 3359 1582 Email: sales@siglent.com Website: int.siglent.com

#### USA:

SIGLENT Technologies America, Inc 6557 Cochran Rd Solon, Ohio 44139 Tel: 440-398-5800 Toll Free: 877-515-5551 Fax: 440-399-1211 Email: info@siglent.com Website: www.siglentna.com

#### **Europe:**

SIGLENT Technologies Germany GmbH Add: Staetzlinger Str. 70 86165 Augsburg, Germany Tel: +49(0)-821-666 0 111 0 Fax: +49(0)-821-666 0 111 22 Email: info-eu@siglent.com

#### Follow us on Facebook: SiglentTech

