

Firmware Update Instructions

Notes : During the updating, do not cut off the power or pull out the U-disk

1. Please firstly copy the update file (.ADS) to U-disk.
2. Insert the U-disk to the USB port.
3. Press **System** button and then press **System Info**, we can enter **Firmware Update** interface.




Figure 1 System menu

4. Press **Firmware Update** and then enter the file system (or you can press **File** button to enter the file system).




Figure 2 System information interface

- Set the **Browser** to **file**. Use the knob or touch screen to select the right update firmware. Then press **Open/Load**, we will see an information window. Press the **Enter** and will see the upgrading information ('hourglass and upgrading now, please wait'). This upgrade program will take about 2~3 minutes.




Figure 3 Update

- When the device upgrading finished, it will restart by itself. We can check the version information in system info(System--System info).




Figure 4 System info