

## SDG Series IVI Specific Driver Installation Guide

### Running Environment

- Operating System: Windows XP, Windows 7
- IVI Compliance Package 4.5 or higher


### Install IVI Compliance Package

Before installing the IVI Specific Driver, please make sure that your PC has installed the IVI Compliance Package. You can get the IVI Compliance Package self-extracting archive from [ni.com/downloads](http://www.ni.com/downloads) by navigating through the Drivers link. (For example, you can get IVI compliance package 15.0 from :


<http://www.ni.com/download/ivi-compliance-package-15.0/5415/en/>)

### SDG Series IVI Specific Driver Installation


1. Double click the installation package sdg.msi. A dialog box will appear as shown below.




2. Click **Next** to continue the installation:




3. Click **Next** to continue the installation:



- Click **Next**, and wait for the installation process to complete



- Installation completes with a message as shown:



6. After the installation, you will find some files located at: “C:/Program Files/IVI Foundation/IVI/” or “C:/Program Files(x86)/IVI Foundation/IVI/”.

The dynamic link library is located in ./Bin, the header file is located in ./Include, the library is located in ./Lib/msc and other files are located in ./Drivers.

Note: We suggest using the dynamic link library. Please make sure you are using the correct path name.